



3 part bowl
60000EM
39X13cm



4 part dish
60153EM
25x25cm



3 part dish
60453EM
41x11.5cm



3 part dish
67414M
36x20cm



Cake plate or 5 part dish
67415M
32x36cm



5 part dish
68648M
31x31cm



3 part dish
68583M
30.5x19cm



Oval plate with 3 bowls
60977EM 30x9.5cm
60980M 50x16cm



Oval plate
60155EM 30x9.5cm
60156EM 41x11.5cm
60157EM 50x16cm



Square bowl
60189EM 11x11cm
60188EM 14x14cm
61038EM 20x20cm
60187M 26x26cm



Leaf bowl
62966EM 19x11cm
62964EM 33x19cm
61201EM 37.5x22cm



Oval bowl
60964EM Ø24cm
60965EM Ø29cm



Basket
63824EM Ø21cm.h.13cm
63825EM Ø33cm.h.20cm



Candy bowl
62969EM 11x11cm
62970EM 14x14cm



Oven dishes
68727M 26x16cm. h.10cm
68728M 32x27cm. h.10.5cm



Star dish & bowl
60532EM 18cm. h7.5cm
63244EM 35cm. h20.5cm



Ice cream bowl
68629M LI.
Ø11cm.h.8cm



Glass cover
65296M
Ø27cm. h.20.5cm



Footed tray
67435M
Ø35cm.h.13cm



2 tiered plate
67452M
Ø21cm.Ø28cm.h.23cm



Jug 1.35lt.
60315 AMBER



Ice bucket
61572EM
14x14cm. h.14.5cm



Set of 6 glasses
62230EM 8x9.5cm. h.11cm
32cl
62232EM 8x9cm. h.14.5cm
40cl



Tumblers
68563M Ø8cm. h.9cm 27cl
68561M Ø8cm. h.14cm 42cl

60331 TURQUOISE
60335 RED